











# svan

## INSTRUCTION MANUAL



Model: 0,5

& SVCA2000MIN

SVAN TRADING S.L.  
C/Ciudad de Cartagena, 20. Paterna (46988). SPAIN.  
info@svanelectro.com  
96060034

## **General Safety Warning:**

1. Read all instructions carefully before using.
2. Make sure the voltage is the same as that indicated on the rating plate of the appliance.
3. Do not operate this appliance if the cable or plug becomes damaged.
4. Keep the appliance and cable away from sources of heat, sharp objects or anything that may cause damage.
5. If the cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
6. Ensure the appliance is switched off before connecting to the mains power supply.
7. Switch off the power supply and disconnect from mains supply when not in use, before cleaning or other maintenance.
8. Turn off the light Switch, disconnect the power supply.
9. The heater must not be located immediately below a socket-outlet.
10. Do not operate in areas where gasoline, paint or other flammable liquids are used or stored.
11. Indoor use only.
12. In order to avoid overheating, do not cover the heater.
13. To prevent a possible fire, do not block air intakes or exhaust in any manner.
14. Do not touch the hot surfaces.
15. Do not insert or allow foreign objects to enter any ventilation or exhaust opening, as this may cause an electric shock, fire, or damage to the appliance.
16. Always ensure that hands are dry before operating or adjusting any switch on the product or touching the plug and socket-outlet.
17. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
18. Children should be supervised to ensure that they do not play with the appliance.
19. Do not leave this appliance unattended when it is in use.
20. The most common cause of overheating is deposits of dust or fluff in the appliance. Ensure these deposits are removed regularly by disconnect the appliance and vacuum cleaning air vents and grilles.
21. Do not place the heater on carpet, do not place the cable under carpets. Arrange cord away from traffic areas so that it will not be tripped over.
22. Do not use this heater in the immediate surroundings of a bath, a shower, or a swimming pool.

23. Do not store away until the heater cools down, store the heater in cool dry location when not in use.


24. When in use, keep the distance between window(wall) at least 50cm

### Technical Specifications:

Model	SVCA2000MIR	SVCA2000MIN
Rated Voltage	220 V -240V~	220 V -240V~
Rated Frequency	50/60 Hz	50/60 Hz
Rated Power	20000W	20000W

### Assembly

3. Insert the wheels into the bottom part of the supporting feet, and to be sure it is tight enough.
4. Put the appliance with upside down, fix the to the appliance with screw.





## Utilization:

- Connect the appliance to safety socket.
- Turn on switch to the heating position (I or II or III).
- The heating functions (III).

Heat setting I	1000W
Heat setting II	2000W

- Turn the thermostat knob in the direction of clockwise until reaching the maximum temperature.
- Once the room temperature is reached, slowly turn the thermostat knob in the direction of anticlockwise until you get your required temperature.
- Turn the switch to "0" position to switch off the heater. Unplug the appliance then after.

## Overheat safety device

- Your heater is fitted with a safety device to switches off the heater in the event of overheating. If the safety device operated, please turn the heater off, unplug the appliance and let it completely cool, inspect for blockage of air inlet or outlet, attempting to restart the heater then after.
- If the heater fails to operate or the safety device switches the heater off again, return heater to your nearest service center for examination or repair.

## Maintenance:

4. Always disconnect the appliance and let it completely cool before any maintenance.
5. Use a vacuum cleaner to remove dust on grilles.
6. Clean the outside of the unit with a damp cloth and then dry it with a dry cloth. Never immerse the unit in water, nor let water drip into the unit.

## **Storing:**

4. Always disconnect the appliance, let it completely cool and clean it before storing.
5. If you do not use the device for a long period, put back the unit and the instruction manual to the original carton and store in a dry and ventilated place.
6. Do not place any heavy items on top of carton during storing as this may damage the appliance.

## **Recycling (Disposal of the product at the end of its life)**



Waste Electrical Products Should Not Be Disposed Of With Household Waste. Please Recycle Where Facilities Exist. Check With Your Local Authority For Recycling Advice.